



Installation Guide



Customer Service
866-491-0973

SSDC Inc. ~ 2901 Belmeade Drive ~ Carrollton, TX ~ 75006-2315

Dispenser Installation above Wash Sink

Step 1

Use enclosed hardware and a 1/4" drill bit. Two mounting screws go at the top of the bracket and one at the bottom. Ensure bracket is no more than 18" from the water source.



Step 2

Insert the top end of the SinkRite™ into the top sleeve of the wall bracket.



Step 3

Use your thumbs to push the SinkRite™ up, and then into the bottom fitting of the wall bracket.



Step 4

Attach discharge hoses to the dispenser.



Step 5

Cut the discharge hoses to length so that the hose hangs about 4" inside the appropriate sink, above the water line.



Easiest Water Connection - Prewash Sprayer



Step 1
Loosen clamp.



Step 2
Unscrew prewash sprayer.



Easiest Water Connection- Prewash Sprayer (continued)

Step 3

Insert "T".



Step 4

Screw in hose fitting and reattach prewash sprayer.



Step 5

Attach hose and connect to the SinkRite™ dispenser.



Water Connection - Faucet

If Prewash Sprayer is not available

Step 1

If Prewash sprayer is not available, remove faucet arm spout.



Step 2

Screw on the bottom part of the faucet adapter, making sure not to screw it down too tightly, otherwise the washer will dislodge.



Step 3

Using Teflon tape, screw the "T" onto the bottom faucet adapter. Tighten until the "T" is facing the same direction as the SinkRite™.



Step 4

Using Teflon tape, screw the brass hose adapter into the side of the "T."



Step 5

Using Teflon tape, screw the nipple into the top of the "T." NOTE: If the ball valve used in Step 11 is threaded, this step is not required.



Water Connection - Faucet (Continued)

If Prewash Sprayer is not available

Step 6

Using teflon tape, screw on ball valve.
Tighten until the knob is facing you.



Step 7

Using teflon tape, screw on the top portion
of the faucet adapter.



Step 8

Reattach faucet arm.



Step 9

Attach 2" water hose to the right side of the
SinkRite™.



Step 10

Attach other end of 2" water hose to the
brass hose connector on the "T."



Final Connections

Step 1

Mount the two racks over the “wash” side of the sink a few inches lower than the dispenser. If wall space is not available, call SSDC for an under-counter rack.



Step 2

Screw blue and red caps onto gallon containers. Connect clear tubing from the blue and red caps to the appropriate intake valve on the SinkRite™ dispenser.



Step 3

Turn on the water.



Step 4

Turn the ball valve to divert the water flow to the SinkRite™.



Step 5

Turn on the dish detergent and sanitizer knobs of the SinkRite™ to prime the lines with chemical. **DO NOT run the dish detergent and sanitizer at the same time.**



Other Items to Install

Sanitizer Test Station
install near 3 compartment sink



Hazard Communication Rack
install in any open area



Spray Bottle Rack



Floor Cleaner Rack
install near mop sink



Packet Cutter
install near floor cleaner rack



Glass and Degreaser Bottle Racks (2)



Soap Dispensers



Tool Rack
optional, ask manager if they want
this installed



Wall Charts





Customer Service
866-491-0973

SSDC Inc. ~ 2901 Belmeade Drive ~ Carrollton, TX ~ 75006-2315